

SHEAR FORCE PHYSICS

UNDERSTANDING SHEAR FORCE IN PHYSICS: A COMPREHENSIVE GUIDE

SHEAR FORCE PHYSICS, AT ITS CORE, DEALS WITH FORCES THAT ACT PARALLEL TO A SURFACE OR OBJECT, CAUSING DEFORMATION BY SLIDING LAYERS OVER ONE ANOTHER. THIS FUNDAMENTAL CONCEPT IS CRUCIAL IN UNDERSTANDING THE BEHAVIOR OF MATERIALS UNDER STRESS, FROM THE SIMPLE ACT OF CUTTING PAPER TO THE COMPLEX STRUCTURAL INTEGRITY OF BUILDINGS AND BRIDGES. WE'LL DELVE DEEP INTO WHAT SHEAR FORCE IS, HOW IT'S MEASURED, ITS REAL-WORLD APPLICATIONS, AND THE CRITICAL ROLE IT PLAYS IN VARIOUS SCIENTIFIC AND ENGINEERING DISCIPLINES. THIS ARTICLE AIMS TO PROVIDE A CLEAR, DETAILED, AND ENGAGING EXPLANATION FOR ANYONE SEEKING TO GRASP THIS ESSENTIAL PHYSICS PRINCIPLE.

TABLE OF CONTENTS

INTRODUCTION TO SHEAR FORCE
DEFINING SHEAR FORCE
DISTINGUISHING SHEAR FORCE FROM OTHER FORCES
QUANTIFYING SHEAR FORCE: THE SHEAR STRESS FORMULA
THE ROLE OF SHEAR STRAIN IN DEFORMATION
TYPES OF SHEAR FORCE
SHEAR FORCE IN ENGINEERING APPLICATIONS
SHEAR FORCE IN EVERYDAY LIFE
UNDERSTANDING SHEAR FAILURE
SHEAR FORCE AND MATERIAL PROPERTIES
CONCLUSION: THE PERVASIVE NATURE OF SHEAR FORCE

DEFINING SHEAR FORCE

SHEAR FORCE, A FUNDAMENTAL CONCEPT IN MECHANICS, DESCRIBES A FORCE THAT ACTS PARALLEL TO A SURFACE. IMAGINE TWO PARALLEL PLANES WITHIN A SOLID MATERIAL. IF YOU APPLY FORCES TO THESE PLANES IN OPPOSITE DIRECTIONS AND PARALLEL TO THEM, YOU'RE INDUCING SHEAR. THIS ACTION CAUSES THE MATERIAL TO DEFORM BY SLIDING ONE LAYER OVER ANOTHER, WITHOUT STRETCHING OR COMPRESSING IT SIGNIFICANTLY. IT'S LIKE SHUFFLING A DECK OF CARDS; THE INDIVIDUAL CARDS SLIDE PAST EACH OTHER. THIS INTERNAL RESISTANCE TO SLIDING IS WHAT WE OFTEN REFER TO AS SHEAR STRESS.

THE KEY CHARACTERISTIC OF SHEAR FORCE IS ITS DIRECTION RELATIVE TO THE OBJECT'S SURFACE. UNLIKE TENSILE FORCES THAT PULL APART OR COMPRESSIVE FORCES THAT PUSH TOGETHER, SHEAR FORCES ATTEMPT TO SLICE OR SLIDE ONE PART OF THE OBJECT PAST ANOTHER. THIS DISTINCTION IS VITAL FOR UNDERSTANDING HOW MATERIALS BEHAVE UNDER DURESS AND PREDICTING POTENTIAL FAILURE POINTS.

DISTINGUISHING SHEAR FORCE FROM OTHER FORCES

IT'S ESSENTIAL TO DIFFERENTIATE SHEAR FORCE FROM OTHER COMMON TYPES OF FORCES ENCOUNTERED IN PHYSICS. WHILE ALL FORCES CAN CAUSE DEFORMATION, THE NATURE OF THAT DEFORMATION IS WHAT SETS THEM APART.

TENSILE FORCE: THIS FORCE PULLS AN OBJECT APART, ATTEMPTING TO STRETCH IT. THINK OF PULLING ON A RUBBER BAND. THE FORCE ACTS PERPENDICULAR TO ANY CROSS-SECTION AND IS DIRECTED OUTWARDS FROM THE CENTER.

COMPRESSIVE FORCE: THIS FORCE PUSHES AN OBJECT TOGETHER, TRYING TO SHORTEN OR CRUSH IT. IMAGINE SQUEEZING A SPONGE. LIKE TENSILE FORCE, IT ACTS PERPENDICULAR TO A CROSS-SECTION BUT IS DIRECTED INWARDS.

BENDING FORCE: THIS IS A COMBINATION OF TENSILE AND COMPRESSIVE FORCES. WHEN YOU BEND A RULER, THE TOP SURFACE IS COMPRESSED, AND THE BOTTOM SURFACE IS STRETCHED.

SHEAR FORCE, ON THE OTHER HAND, ACTS PARALLEL TO THE SURFACE. THIS PARALLEL ACTION IS WHAT LEADS TO THE CHARACTERISTIC SLIDING OR SHEARING DEFORMATION. UNDERSTANDING THESE DISTINCTIONS HELPS IN ANALYZING THE STRESSES AND STRAINS WITHIN ANY GIVEN STRUCTURE OR MATERIAL.

QUANTIFYING SHEAR FORCE: THE SHEAR STRESS FORMULA

TO UNDERSTAND THE EFFECT OF SHEAR FORCE QUANTITATIVELY, WE INTRODUCE THE CONCEPT OF SHEAR STRESS. SHEAR STRESS, DENOTED BY THE GREEK LETTER TAU (τ), IS DEFINED AS THE SHEAR FORCE (F) ACTING PARALLEL TO A SURFACE DIVIDED

BY THE AREA (A) OVER WHICH THAT FORCE IS DISTRIBUTED. THE FORMULA IS ELEGANTLY SIMPLE:

$$\tau = F / A$$

HERE'S A BREAKDOWN OF THE COMPONENTS:

SHEAR FORCE (F): THIS IS THE MAGNITUDE OF THE FORCE APPLIED PARALLEL TO THE SURFACE. ITS UNIT IS TYPICALLY NEWTONS (N) IN THE SI SYSTEM.

AREA (A): THIS IS THE CROSS-SECTIONAL AREA OF THE OBJECT THAT IS RESISTING THE SHEAR. IT'S THE AREA OF THE PLANE PARALLEL TO THE APPLIED FORCES. ITS UNIT IS TYPICALLY SQUARE METERS (M²).

SHEAR STRESS (τ): THIS REPRESENTS THE INTERNAL RESISTANCE PER UNIT AREA WITHIN THE MATERIAL TO THE APPLIED SHEAR FORCE. ITS UNIT IS PASCALS (Pa) OR NEWTONS PER SQUARE METER (N/M²).

A HIGHER SHEAR STRESS INDICATES THAT THE MATERIAL IS EXPERIENCING A GREATER INTERNAL RESISTANCE TO SLIDING, AND THUS, IS CLOSER TO ITS BREAKING POINT IF THE FORCE CONTINUES TO INCREASE. THIS FORMULA IS FUNDAMENTAL IN ENGINEERING DESIGN, ALLOWING PROFESSIONALS TO CALCULATE THE STRESSES A MATERIAL WILL ENDURE AND SELECT APPROPRIATE MATERIALS THAT CAN WITHSTAND THEM.

THE ROLE OF SHEAR STRAIN IN DEFORMATION

WHILE SHEAR STRESS QUANTIFIES THE INTERNAL RESISTANCE TO SLIDING, SHEAR STRAIN QUANTIFIES THE RESULTING DEFORMATION. SHEAR STRAIN, OFTEN DENOTED BY THE GREEK LETTER GAMMA (γ), IS A MEASURE OF THE ANGULAR DISTORTION THAT OCCURS IN A MATERIAL WHEN SUBJECTED TO SHEAR STRESS. IT'S DEFINED AS THE RATIO OF THE RELATIVE DISPLACEMENT (Δx) OF THE PARALLEL PLANES TO THE DISTANCE (L) BETWEEN THEM.

$$\gamma = \Delta x / L$$

IMAGINE A RECTANGULAR BLOCK. WHEN SUBJECTED TO SHEAR FORCE, THE TOP FACE MIGHT SLIDE A DISTANCE Δx RELATIVE TO THE BOTTOM FACE, WHICH IS SEPARATED BY A HEIGHT L. THE RESULTING SHAPE WILL BE A PARALLELOGRAM, AND THE SHEAR STRAIN IS A MEASURE OF HOW "SKEWED" THAT PARALLELOGRAM BECOMES. UNLIKE LINEAR STRAIN (WHICH MEASURES STRETCHING OR COMPRESSION), SHEAR STRAIN IS DIMENSIONLESS, OR CAN BE EXPRESSED IN RADIANS.

THE RELATIONSHIP BETWEEN SHEAR STRESS AND SHEAR STRAIN IS OFTEN LINEAR FOR ELASTIC MATERIALS, AS DESCRIBED BY HOOKE'S LAW FOR SHEAR. THIS RELATIONSHIP IS CHARACTERIZED BY THE SHEAR MODULUS (G), ALSO KNOWN AS THE MODULUS OF RIGIDITY:

$$G = \tau / \gamma$$

THE SHEAR MODULUS IS A MATERIAL PROPERTY THAT INDICATES ITS RESISTANCE TO SHEAR DEFORMATION. A MATERIAL WITH A HIGH SHEAR MODULUS IS STIFF AND REQUIRES A LARGE SHEAR STRESS TO PRODUCE A SMALL SHEAR STRAIN, WHILE A MATERIAL WITH A LOW SHEAR MODULUS IS MORE EASILY DEFORMED BY SHEAR FORCES.

TYPES OF SHEAR FORCE

SHEAR FORCES CAN MANIFEST IN VARIOUS WAYS, DEPENDING ON THE GEOMETRY OF THE OBJECT AND HOW THE FORCES ARE APPLIED. UNDERSTANDING THESE DIFFERENT TYPES HELPS IN ANALYZING SPECIFIC SCENARIOS.

DIRECT SHEAR: THIS IS THE MOST STRAIGHTFORWARD TYPE, WHERE A FORCE IS APPLIED DIRECTLY PARALLEL TO A CROSS-SECTION, ATTEMPTING TO CUT OR SLIDE IT. EXAMPLES INCLUDE SCISSORS CUTTING PAPER OR A BOLT BEING SHEARED.

TORSIONAL SHEAR: THIS OCCURS WHEN A TWISTING FORCE IS APPLIED TO AN OBJECT, SUCH AS A SHAFT ROTATING. WHILE THE PRIMARY EFFECT IS ROTATION, THE INTERNAL STRESSES ARE A FORM OF SHEAR STRESS. THINK OF TWISTING A TOWEL.

TRANSVERSE SHEAR: THIS OFTEN OCCURS IN BEAMS SUBJECTED TO BENDING LOADS. THE SHEAR FORCE IN A BEAM IS TYPICALLY NOT UNIFORM AND IS A CONSEQUENCE OF THE VARYING BENDING MOMENT ALONG ITS LENGTH.

EACH TYPE OF SHEAR FORCE LEADS TO A DISTINCT STRESS DISTRIBUTION WITHIN THE MATERIAL AND CAN BE ANALYZED USING SPECIFIC ENGINEERING FORMULAS AND PRINCIPLES.

SHEAR FORCE IN ENGINEERING APPLICATIONS

THE PRINCIPLES OF SHEAR FORCE ARE ABSOLUTELY CRITICAL IN COUNTLESS ENGINEERING DISCIPLINES. STRUCTURAL ENGINEERS, MECHANICAL ENGINEERS, AND MATERIAL SCIENTISTS ALL RELY ON A THOROUGH UNDERSTANDING OF SHEAR TO DESIGN SAFE AND EFFICIENT STRUCTURES AND COMPONENTS.

BUILDING DESIGN: WHEN DESIGNING BEAMS, COLUMNS, AND CONNECTIONS IN BUILDINGS, ENGINEERS MUST ACCOUNT FOR SHEAR FORCES CAUSED BY GRAVITY LOADS, WIND, AND EARTHQUAKES. THE WAY BEAMS ARE CONNECTED TO COLUMNS, FOR INSTANCE, IS SPECIFICALLY DESIGNED TO RESIST SHEAR.

BRIDGE CONSTRUCTION: BRIDGES ARE CONSTANTLY SUBJECTED TO SHEAR FORCES FROM TRAFFIC, WIND, AND THEIR OWN WEIGHT. THE MATERIALS AND STRUCTURAL ELEMENTS MUST BE ABLE TO WITHSTAND THESE FORCES WITHOUT FAILING. THE SHEAR STRENGTH OF THE CONCRETE AND STEEL USED IS A PRIMARY CONSIDERATION.

MECHANICAL COMPONENTS: MANY MACHINE PARTS EXPERIENCE SHEAR. SHAFTS IN ENGINES, GEARS, AND EVEN SIMPLE FASTENERS LIKE RIVETS AND BOLTS ARE ALL DESIGNED WITH SHEAR STRENGTH IN MIND. A BOLT FAILING DUE TO SHEAR IS A COMMON SCENARIO IN MECHANICAL FAILURES.

FLUID DYNAMICS: WHILE THIS ARTICLE FOCUSES ON SOLID MECHANICS, IT'S WORTH NOTING THAT THE CONCEPT OF SHEAR IS ALSO FUNDAMENTAL IN FLUID MECHANICS, WHERE "VISCOUS SHEAR" DESCRIBES THE FRICTION BETWEEN FLUID LAYERS MOVING AT DIFFERENT SPEEDS.

WITHOUT A DEEP UNDERSTANDING OF SHEAR FORCE, THE STRUCTURES AND MACHINES WE RELY ON DAILY WOULD BE PRONE TO CATASTROPHIC FAILURE.

SHEAR FORCE IN EVERYDAY LIFE

YOU MIGHT BE SURPRISED AT HOW OFTEN YOU ENCOUNTER SHEAR FORCES IN YOUR DAILY LIFE, OFTEN WITHOUT REALIZING IT. THESE FORCES ARE EVERYWHERE, PLAYING A ROLE IN SIMPLE TASKS AND COMMON OBJECTS.

CUTTING WITH A KNIFE: WHEN YOU SLICE VEGETABLES OR MEAT WITH A KNIFE, YOU ARE APPLYING A SHEAR FORCE. THE BLADE IS DESIGNED TO CREATE A CONCENTRATED SHEAR STRESS ALONG A THIN LINE, CAUSING THE FOOD TO SEPARATE.

USING SCISSORS: SCISSORS ARE A PRIME EXAMPLE OF DIRECT SHEAR. THE TWO BLADES MOVE PAST EACH OTHER, APPLYING PARALLEL FORCES THAT SHEAR THROUGH PAPER, FABRIC, OR OTHER MATERIALS.

WALKING: WHILE NOT AS OBVIOUS, THE FRICTION BETWEEN YOUR SHOES AND THE GROUND CREATES SHEAR FORCES THAT ALLOW YOU TO PROPEL YOURSELF FORWARD. THIS IS A FORM OF SHEAR STRESS ON THE SOLES OF YOUR SHOES AND THE GROUND.

FASTENING WITH STAPLES OR RIVETS: WHEN YOU STAPLE PAPERS TOGETHER OR USE RIVETS TO JOIN TWO PIECES OF METAL, THE STAPLE OR RIVET IS DESIGNED TO RESIST SHEAR FORCES THAT WOULD TRY TO PULL THE FASTENED MATERIAL APART.

OPENING A JAR WITH A LID: WHEN YOU TWIST A STUBBORN JAR LID, YOU ARE APPLYING A TORSIONAL SHEAR FORCE TO THE LID, AND THE LID APPLIES A SHEAR FORCE TO THE THREADS OF THE JAR.

THESE EVERYDAY EXAMPLES ILLUSTRATE THAT SHEAR FORCE IS NOT JUST AN ABSTRACT PHYSICS CONCEPT BUT A TANGIBLE FORCE THAT INFLUENCES OUR INTERACTIONS WITH THE WORLD AROUND US.

UNDERSTANDING SHEAR FAILURE

SHEAR FAILURE OCCURS WHEN THE APPLIED SHEAR STRESS WITHIN A MATERIAL EXCEEDS ITS SHEAR STRENGTH, LEADING TO FRACTURE OR PERMANENT DEFORMATION. THIS IS A CRITICAL CONSIDERATION IN MATERIAL SCIENCE AND ENGINEERING DESIGN.

THERE ARE SEVERAL WAYS A MATERIAL CAN FAIL UNDER SHEAR:

DUCTILE SHEAR FAILURE: IN DUCTILE MATERIALS, FAILURE IS CHARACTERIZED BY SIGNIFICANT DEFORMATION BEFORE FRACTURE. THE MATERIAL MIGHT STRETCH OR YIELD CONSIDERABLY ALONG THE SHEAR PLANE.

BRITTLE SHEAR FAILURE: BRITTLE MATERIALS, SUCH AS GLASS OR CERAMICS, TEND TO FRACTURE SUDDENLY WITH LITTLE OR NO PRIOR DEFORMATION WHEN SUBJECTED TO SHEAR STRESS EXCEEDING THEIR LIMIT.

PUNCHING SHEAR: THIS TYPE OF FAILURE IS COMMON IN FLAT SLABS, LIKE CONCRETE FLOORS, WHEN A CONCENTRATED LOAD IS APPLIED OVER A SMALL AREA, CAUSING THE MATERIAL TO "PUNCH" THROUGH.

UNDERSTANDING THE SHEAR STRENGTH OF A MATERIAL IS PARAMOUNT. IT'S THE MAXIMUM SHEAR STRESS A MATERIAL CAN WITHSTAND BEFORE IT BEGINS TO FAIL. THIS VALUE IS DETERMINED THROUGH STANDARDIZED MATERIAL TESTING AND IS CRUCIAL FOR ENSURING THE SAFETY AND RELIABILITY OF ENGINEERED PRODUCTS.

SHEAR FORCE AND MATERIAL PROPERTIES

THE WAY A MATERIAL RESPONDS TO SHEAR FORCE IS INTRINSICALLY LINKED TO ITS INHERENT PROPERTIES. DIFFERENT MATERIALS EXHIBIT VASTLY DIFFERENT BEHAVIORS UNDER SHEAR STRESS, DICTATING THEIR SUITABILITY FOR VARIOUS APPLICATIONS.

METALS: GENERALLY POSSESS HIGH SHEAR STRENGTH AND A MODERATE TO HIGH SHEAR MODULUS. THEY ARE DUCTILE, MEANING THEY CAN UNDERGO SIGNIFICANT DEFORMATION BEFORE FAILURE, MAKING THEM SUITABLE FOR STRUCTURAL COMPONENTS, FASTENERS, AND MACHINE PARTS.

POLYMERS (PLASTICS): EXHIBIT A WIDE RANGE OF SHEAR PROPERTIES. SOME ARE QUITE FLEXIBLE AND HAVE LOW SHEAR STRENGTH, WHILE OTHERS ARE REINFORCED AND CAN WITHSTAND CONSIDERABLE SHEAR. THEIR DEFORMATION UNDER SHEAR CAN BE ELASTIC OR PLASTIC.

CERAMICS: ARE TYPICALLY BRITTLE WITH VERY HIGH COMPRESSIVE STRENGTH BUT OFTEN HAVE LOWER SHEAR STRENGTH COMPARED TO DUCTILE METALS. THEY FAIL SUDDENLY UNDER SHEAR.

COMPOSITES: MATERIALS LIKE CARBON FIBER COMPOSITES CAN BE ENGINEERED TO HAVE EXCEPTIONAL SHEAR STRENGTH IN SPECIFIC DIRECTIONS, MAKING THEM IDEAL FOR HIGH-PERFORMANCE APPLICATIONS IN AEROSPACE AND AUTOMOTIVE INDUSTRIES.

THE SELECTION OF MATERIALS FOR ANY APPLICATION WHERE SHEAR FORCES ARE PRESENT RELIES HEAVILY ON UNDERSTANDING THESE MATERIAL PROPERTIES AND HOW THEY INTERACT WITH THE EXPECTED SHEAR STRESSES.

CONCLUSION: THE PERVASIVE NATURE OF SHEAR FORCE

FROM THE INTRICATE WORKINGS OF A MICROSCOPIC SCREW TO THE COLOSSAL SPAN OF A SUSPENSION BRIDGE, SHEAR FORCE IS A FUNDAMENTAL AND PERVASIVE PHENOMENON IN THE PHYSICAL WORLD. IT DICTATES HOW OBJECTS DEFORM, HOW THEY BREAK, AND HOW WE DESIGN THE ENGINEERED MARVELS THAT SHAPE OUR MODERN LIVES. BY UNDERSTANDING THE PRINCIPLES OF SHEAR FORCE, SHEAR STRESS, AND SHEAR STRAIN, WE GAIN A DEEPER APPRECIATION FOR THE MECHANICS THAT GOVERN OUR ENVIRONMENT AND THE INGENUITY REQUIRED TO HARNESS THESE FORCES SAFELY AND EFFECTIVELY. WHETHER IN THE LAB, THE WORKSHOP, OR SIMPLY OBSERVING THE WORLD AROUND US, THE INFLUENCE OF SHEAR FORCE IS UNDENIABLE.

FAQ

Q: WHAT IS THE DIFFERENCE BETWEEN SHEAR STRESS AND SHEAR FORCE?

A: SHEAR FORCE IS THE APPLIED FORCE THAT ACTS PARALLEL TO A SURFACE, WHILE SHEAR STRESS IS THE INTERNAL RESISTANCE PER UNIT AREA WITHIN THE MATERIAL TO THAT APPLIED FORCE. SHEAR FORCE IS THE CAUSE, AND SHEAR STRESS IS THE EFFECT WITHIN THE MATERIAL.

Q: HOW IS SHEAR FORCE RELATED TO BENDING IN BEAMS?

A: IN BEAMS SUBJECTED TO BENDING LOADS, SHEAR FORCES ARE ALWAYS PRESENT, ACTING PERPENDICULAR TO THE LONGITUDINAL AXIS OF THE BEAM. THE SHEAR FORCE IS NOT UNIFORM ALONG THE LENGTH OF THE BEAM AND IS DIRECTLY RELATED TO THE RATE OF CHANGE OF THE BENDING MOMENT.

Q: CAN SHEAR FORCE CAUSE A MATERIAL TO STRETCH?

A: NO, SHEAR FORCE DOES NOT CAUSE STRETCHING OR COMPRESSION. IT CAUSES A DEFORMATION WHERE ONE PART OF THE MATERIAL SLIDES OVER ANOTHER, RESULTING IN AN ANGULAR DISTORTION OR SHEARING OF THE MATERIAL'S SHAPE.

Q: WHAT IS THE SHEAR STRENGTH OF A MATERIAL?

A: THE SHEAR STRENGTH OF A MATERIAL IS THE MAXIMUM SHEAR STRESS IT CAN WITHSTAND BEFORE IT BEGINS TO FAIL, EITHER THROUGH FRACTURE OR PERMANENT DEFORMATION. IT'S A CRITICAL MATERIAL PROPERTY FOR DESIGN.

Q: ARE SHEAR FORCES ALWAYS HARMFUL?

A: NOT NECESSARILY. WHILE EXCESSIVE SHEAR FORCES CAN LEAD TO FAILURE, SHEAR FORCES ARE ALSO ESSENTIAL FOR MANY FUNCTIONAL PROCESSES, SUCH AS THE OPERATION OF CUTTING TOOLS, THE GRIP PROVIDED BY FRICTION, AND THE MECHANICS

OF MANY MACHINES.

Q: HOW DOES TEMPERATURE AFFECT SHEAR FORCE AND STRESS?

A: TEMPERATURE CAN SIGNIFICANTLY AFFECT A MATERIAL'S SHEAR STRENGTH AND SHEAR MODULUS. GENERALLY, AS TEMPERATURE INCREASES, MOST MATERIALS TEND TO BECOME WEAKER AND MORE DUCTILE, MEANING THEIR SHEAR STRENGTH DECREASES, AND THEIR ABILITY TO DEFORM BEFORE FRACTURE INCREASES.

Q: WHAT IS THE ROLE OF SHEAR FORCE IN EVERYDAY TOOLS LIKE SCISSORS?

A: SCISSORS WORK BY APPLYING TWO OPPOSITE SHEAR FORCES THAT ARE CONCENTRATED ALONG THE THIN EDGES OF THE BLADES. THIS CREATES A HIGH SHEAR STRESS IN THE MATERIAL BEING CUT, CAUSING IT TO SEPARATE ALONG THAT LINE.

Q: CAN A FLUID EXPERIENCE SHEAR FORCE?

A: YES, FLUIDS CAN EXPERIENCE SHEAR FORCES, PARTICULARLY WHEN THERE IS A VELOCITY GRADIENT BETWEEN ADJACENT LAYERS OF THE FLUID. THIS IS KNOWN AS VISCOUS SHEAR, AND IT'S A FUNDAMENTAL CONCEPT IN FLUID MECHANICS AND RHEOLOGY.

Shear Force Physics

Shear Force Physics

Related Articles

- [realistic ragdoll physics](#)
- [sigma meaning in physics](#)
- [stanford physics faculty](#)

[Back to Home](#)